



APÉNDICE 1
MANUAL TÉCNICO

Página 1/27

TSR ABA 00/16

SERVICIO DE MANTENIMIENTO
GRUPO ELECTRÓGENO

HEIMER

Grupos Geradores

Grupos Electrógenos - Generator Sets

DPC 560

Descrição dos Pinos

Modo de Funcionamento

GRUPO GERADOR ELECTRICO

By Jorge Saboia

1. FUNCIONALIDADE

O DPC 560 tem função similar ao DPC 500. A chave frontal seleciona o modo de operação que são os seguintes:

a) OFF

Ao posicionar a chave frontal na posição **OFF**, o grupo gerador é desligado e todas as falhas memorizadas são repostas.

b) AUTOMÁTICO

Ao posicionar a chave frontal na posição **AUTOMÁTICO**, a condição do grupo fica inalterada, isto é, se o grupo estiver desligado com o sinal **TENSÃO REDE** desativo (indicação de rede normal) o mesmo permanece desligado. Se o grupo estiver ligado, o mesmo permanecerá ligado se o sinal **TENSÃO REDE** estiver ativo (indicação de rede anormal). Caso contrário o sinal **TRANSFERE CARGA** é desativado e o grupo entra na temporização de arrefecimento.

Caso o grupo esteja desligado e o sinal de entrada **TENSÃO REDE** fique ativo indicando uma anormalidade da rede comercial, é iniciada uma temporização de 5 segundos.

Finda esta temporização é caracterizada a condição de **REDE ANORMAL**, sendo iniciada a seqüência de partida do grupo. São efetuadas 3 tentativas de partida com intervalo de 15 segundos entre cada tentativa. Caso o grupo não parta, é sinalizado **FALHA NA PARTIDA**.

Após o grupo partir é iniciada uma temporização de espera de estabilização do grupo. Finda esta temporização, é ativado o sinal **TRANSFERE CARGA**.

Quando o sinal **TENSÃO REDE** retomar a condição de desativo, indicando a volta a normalidade da rede comercial, é iniciada uma temporização de confirmação. Finda esta temporização, o sinal **TRANSFERE CARGA** é desativado sendo iniciada uma temporização de arrefecimento do grupo gerador. Se durante a temporização o sinal de **TENSÃO REDE** voltar a ficar ativo (indicação de rede anormal), o sinal **TRANSFERE CARGA** é novamente ativado e a temporização de arrefecimento é cancelada. Finda a temporização de arrefecimento, o grupo é desligado.

c) MANUAL

Ao posicionar a chave frontal na posição **MANUAL**, iniciado um teste de leds e campanha durante 2 segundos. Neste teste, todos os leds e a campanha ficam ativos. Finda esta temporização os leds e a campanha volta a condição normal. Imediatamente após o teste de leds e campanha, é iniciada a seqüência de partida do grupo. São efetuadas 3 tentativas de partida com intervalo de 15 segundos entre cada tentativa. Caso o grupo não parta, é sinalizado **FALHA NA PARTIDA**.

Após o grupo partir é iniciada uma temporização de espera de estabilização do grupo. Finda esta temporização, o grupo fica em vazio.

Caso o sinal **TENSÃO REDE** fique ativo indicando a condição de rede comercial anormal, o sinal **TRANSFERE CARGA** é imediatamente ativado, o sinal **TRANSFERE CARGA** irá permanecer ativo mesmo que o sinal de **TENSÃO REDE** volte a ficar desativo (condição de rede normal).

Esta condição permanecerá até que o grupo apresente alguma falha ou a posição chave seja alterada.

Os pinos tem a seguinte função:

Pino	Descrição	
1	Nome	Positivo Bateria.
	Função	Alimentação do módulo.
	Tipo	Entrada analógica.
	atuação	
2	Nome	Arranque.
	Função	Acionamento do motor de arranque.
	Tipo	Saída digital.
	atuação	Negativo da bateria indicando ativação do motor de arranque.
3	Nome	Solenóide Combustível S.A.
	Função	Liberção de óleo combustível.
	Tipo	Saída digital.
	atuação	Negativo bateria indicando a liberaçõ do óleo combustível.
4	Nome	Tensão Rede.
	Função	Indicaçõ da condiçõ da tensõ da rede comercial.
	Tipo	Entrada digital.
	atuação	Negativo da bateria indicando tensõ da dede anormal.
5	Nome	Tensão Gerador.
	Função	Indicaçõ da condiçõ da tensõ do gerador.
	Tipo	Entrada digital.
	atuação	Negativo da bateria indicando tensõ da gerador anormal.
6	Nome	Sobrecarga.
	Função	Sinal externo indicando condiçõp da corrente de consumidor.
	Tipo	Entrada digital.
	atuação	Negativo da bateria indicando sobrecarga.
7	Nome	Pressão Anormal.
	Função	Indicaçõ de pressõ do óleo lubrificante.
	Tipo	Entrada digital.
	atuação	Negativo da bateria indicando pressõ baixa.
8	Nome	Temperatura Anormal.
	Função	Indicaçõ de temperatura da água do motor.
	Tipo	Entrada digital.
	atuação	Negativo da bateria indicando temperatura alta.
9	Nome	Solenóide combustível SF.
	Função	Bloqueio do óleo combustível.
	Tipo	Saída digital
	atuação	Negativo da bateria indicando bloqueio do óleo combustível
10	Nome	Transfere Carga.
	Função	Indicaçõ da condiçõ normal do gerador.
	Tipo	Saída digital.
	atuação	Negativo da bateria indicando gerador pode assumir carga.
11	Nome	Automático.
	Função	Indicaçõ da condiçõ de operaçõ do DPC.
	Tipo	Saída digital.
	atuação	Negativo da bateria indicando DPC na condiçõ de automático.
12	Nome	Carga Bateria.
	Função	Tensõ de saída do alternador de carga de bateria.
	Tipo	Entrada analógica.
	atuação	
13	Nome	Tensõ Saída Gerador.
	Função	Tensõ senoidal da saída do gerador para leitura da freqüencia.
	Tipo	Entrada analógica.
	atuação	
14	Nomo	Negativo da Bateria.
	Função	Alimentação do módulo.
	Tipo	Entrada analógica.
	atuação	

3. FUNÇÃO DOS LEDS


Os leds do painel frontal tem a função de informar ao operador de eventos detectados pelo DPC. A função de cada led é a seguinte:

LED	COR	FUNÇÃO
Tensão Rede	Vermelho	Indicação de tensão anormal da rede.
Tensão GMG	Vermelho	Indicação de tensão anormal do GMG.
Proteção Ativada	Verde	Indicação de sensores ativados.
GMG Operando	Verde	Indicação de ativada após a partida do GMG.
Carga Bateria	Vermelho	Indicação de falha na carga da bateria de partida.
Pressão Anormal	Vermelho	Indicação de pressão anormal de óleo lubrificante.
Temperatura Anormal	Vermelho	Indicação de temperatura alta da água do motor.
Sobrecarga	Vermelho	Indicação de sobrecarga de corrente no consumidor.
Rotação Anormal	Vermelho	Indicação de frequência anormal ou sobrevelocidade.
Falha na Partida	Vermelho	Indicação de GMG não partiu após 3 tentativas.
Proteção	Vermelho	Indicação da detecção de alguma falha no GMG.

DIMENSIONS

Module Dimensions - 240mm x 172mm x 57mm (9.5" x 6.8" x 2.3")
 Panel cutout - 220mm x 160mm (8.7" x 6.3")

TYPICAL WIRING DIAGRAM



Deep Sea Electronics Plc.
 Highfield House, Hunmanby Industrial Estate,
 North Yorkshire, YO14 0PH, ENGLAND
 Tel +44 (0)1723 890099.
 Fax +44 (0)1723 893303.
 Email - sales@deepseapl.com
 web - www.deepseapl.com

Deep Sea Electronics Inc.
 5301 E. State St. - Suite 202
 Rockford, Illinois 61108, U.S.A.
 Phone +1 (815) 316-8706
 Fax +1 (815) 316-8708
 Email - dsales@deepseausa.com
 Web - www.deepseausa.com




DEEP SEA ELECTRONICS

ISSUE 2

Model 5110 Configuration and installation instructions

ACCESSING THE CONFIGURATION EDITOR

Operate the Configuration mode switch into the "configure" position. (This recessed switch is located on the rear of the module in the top right corner when viewing the module from the back.)



The LED indicator beside the AUTO ✓ button will flash to show that the module is now in configuration mode. While in configuration mode, all normal operation is suspended.

The first configurable parameter is displayed. In this example, the Start delay timer (parameter 0). Is currently set to 5s.



NOTE:- The module must be in STOP mode with the engine at rest in order to enter the configuration editor.

EDITING AN ANALOGUE VALUE


Enter the configuration editor as described above.

Press the + / - buttons to select the parameter you wish to change using the following lists as a reference.

Press the ✓ button to enter adjust mode. The ↑ ↓ icons in the module display will flash. Pressing the + or - buttons while the ↑ ↓ icons are flashing will change the selected parameter to the desired value.

Press the ✓ button to 'save' the value. The ↑ ↓ icons will stop flashing to confirm that it has been saved.

The parameter being displayed in this example is the cooling timer (parameter 19). It's current value is 2.5mins (2mins 30secs).



EDITING A 'LIST' VALUE

Some configuration parameters have a list of options to select from. These include input and output settings.

This example shows the setting for oil pressure transducer (parameter 19). It's current setting is 3 ('VDO 0-10bar' from the list shown opposite).



NOTE:- When in adjust mode (indicated by the flashing ↑ ↓ icons in the module display), pressing the 0 (stop mode) button will cancel any changes made to the current parameter, reverting to the last 'saved' value. This also exits adjust mode.

NOTE:- To exit the front panel configuration editor at any time, move the Configuration mode switch back into the "normal" position. Ensure you save any changes you have made by pressing the ✓ button first if necessary.

TIMERS & ANALOGUE SETTINGS

Parameter	Type	Default	Max
0 - Start delay	Timer	5s	60s 3
1 - Preheat	Timer	0s	60s 0
2 - Crank attempt	Timer	10s	60s 6
3 - Crank rest	Timer	10s	60s 10
4 - Safety delay	Timer	8s	60s 12
5 - Warming up	Timer	0s	60s 0
6 - Return delay	Timer	30s	60m 30
7 - Cooling run	Timer	60s	60m 3.0
8 - E.T.S. solenoid hold	Timer	0s	60s 12
9 - Low Oil Pressure	Trip	15PSI	150PSI 15
10 - High Temperature	Trip	95°C	150°C 97
11 - Under Speed	Trip	1250RPM	3600RPM 134
12 - Over Speed	Trip	1750RPM	5000RPM 161
13 - Underfrequency	Trip	40Hz	60Hz 47
14 - Overfrequency	Trip	57Hz	72Hz 56
15 - Charge Alt Failure	Warning	8V DC	25V DC 8
16 - Flywheel teeth	Value	0	300 157
17 - CT Primary	Value	500A	8000A 300

NOTE:- Setting a timer to zero (0) will disable it. Timer settings increment from 0 to 60s in steps of 1s and from 1 minute to the maximum value in steps of 30 seconds (0.5 minutes) (where applicable)

NOTE:- Setting Flywheel teeth to zero (0) will disable magnetic pickup speed sensing. In this instance, engine speed is derived from the alternator output frequency.

NOTE:- CT values increment from 10-100 in steps of 10A, and from 100 to 6000A in steps of 50A. CT secondary must be 5A.

LIST ITEM SETTINGS

Factory default settings are in *bold italicised text*.

Parameter	Selections
18 - Alternator poles	4 0,2,4,6,8
19 - Oil Pressure transducer	0 - Switch close to activate 1 - Switch open to activate 2 - VDO 0-5bar 3 - VDO 0-10bar 4 - Datcon 0-5bar 5 - Datcon 0-10bar
20 - Coolant temp transducer	0 - Switch close to activate 1 - Switch open to activate 2 - VDO 0-120°C 3 - Datcon High
21 - Fast loading enabled	0 - No 1 - Yes
22 - AC system	1 - 1 phase 2-wire 3 - 3 phases 4 wires
23 - Oil pressure display units	0 - Bar/PSI 1 - kPa

CONFIGURABLE OUTPUTS

Factory default settings are in **bold italicised** text.

Parameter	Selection
24 - Output 1	0 - Unused
	1 - <i>Preheat mode 0</i>
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	
25 - Output 2	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	
26 - Output 3	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	

LCD INDICATORS

Factory default settings are in **bold italicised** text.

Parameter	Selection
27 - LCD 1	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	
28 - LCD 2	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	

LCD INDICATORS (CONTINUED)

Factory default settings are in **bold italicised** text.

Parameter	Selection
29 - LCD 3	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	
30 - LCD 4	0 - Unused
	1 - Preheat mode 0
	2 - Air flap
	3 - Load transfer
	4 - Energise to stop
	5 - Engine running
	6 - Shutdown alarm
	7 - System in auto
	8 - Auxiliary input 1 active
	9 - Auxiliary input 2 active
	10 - Auxiliary input 3 active
	11 - Auxiliary input 4 active
	12 - Auxiliary input 5 active
	13 - Preheat mode 1
	14 - Preheat mode 2
	15 - Preheat mode 3
	16 - Warning alarm
17 - Common alarm	

CONFIGURABLE INPUTS


Factory default settings are in **bold italicised** text.

Parameter	Selection
31 - Input 1	0 - Delayed, Warning, close to activate
	1 - Delayed, Warning, open to activate
	2 - Immediate, Warning, close to activate
	3 - Immediate, Warning, open to activate
	4 - Delayed, Shutdown, close to activate
	5 - Delayed, Shutdown, open to activate
	6 - Immediate, Shutdown, close to activate
	7 - Immediate, Shutdown, open to activate
	8 - Remote Start, close to activate
9 - Remote Start, open to activate	
32 - Input 2	0 - Delayed, Warning, close to activate
	1 - Delayed, Warning, open to activate
	2 - Immediate, Warning, close to activate
	3 - Immediate, Warning, open to activate
	4 - Delayed, Shutdown, close to activate
	5 - Delayed, Shutdown, open to activate
	6 - Immediate, Shutdown, close to activate
	7 - Immediate, Shutdown, open to activate
	8 - Electrical trip, close to activate
9 - Electrical trip, open to activate	
33 - Input 3	0 - Warning, Delayed, close to activate
	1 - Warning, Delayed, open to activate
	2 - Warning, Immediate, close to activate
	3 - Warning, Immediate, open to activate
	4 - Shutdown, Delayed, close to activate
	5 - Shutdown, Delayed, open to activate
	6 - Shutdown, Immediate, close to activate
	7 - Immediate, Shutdown, open to activate
	8 - Lamp test, close to activate
9 - Lamp test, open to activate	
34 - Input 4	0 - Delayed, Warning, close to activate
	1 - Delayed, Warning, open to activate
	2 - Immediate, Warning, close to activate
	3 - Immediate, Warning, open to activate
	4 - Delayed, Shutdown, close to activate
	5 - Delayed, Shutdown, open to activate
	6 - Immediate, Shutdown, close to activate
	7 - Immediate, Shutdown, open to activate
	8 - Lamp test, close to activate
9 - Lamp test, open to activate	
35 - Input 5	0 - Delayed, Warning, close to activate
	1 - Delayed, Warning, open to activate
	2 - Immediate, Warning, close to activate
	3 - Immediate, Warning, open to activate
	4 - Delayed, Shutdown, close to activate
	5 - Delayed, Shutdown, open to activate
	6 - Immediate, Shutdown, close to activate
7 - Immediate, Shutdown, open to activate	


NOTE:- The 'preheat modes' selectable for configurable outputs and LCD indicators perform the following actions :

- Preheat mode 0 - Preheat during preheat timer, ceasing at end of preheat timer.
- Preheat mode 1 - Preheat during preheat timer and continue until engine stops cranking.
- Preheat mode 2 - Preheat during preheat timer and continue until the safety delay timer has expired.
- Preheat mode 3 - Preheat during preheat timer and continue until the warning timer has expired.


In addition, in all preheat modes, preheat takes place during the crank rest timer between crank cycles.




VISTA FRONTAL DO QUADRO DE COMANDO



VISTA INTERNA DO QUADRO DE COMANDO



PERFIL LATERAL



VISTA INFERIOR DO QUADRO DE COMANDO

POTÊNCIA: 160KVA TENSÃO: 380/220V/50Hz		NOME: CLEDSON DATA: JAN/04		VISTO: [assinatura]		CLIENTE: MAINTEN S.R.L.		OP.: 4E0394	
RESPONSÁVEL TÉCNICO: ALCIDES CARLOS R. DA SILVA REG. CREA Nº 0346/83		PROJ.: CLEDSON DATA: JAN/04		DES.: CLEDSON DATA: [assinatura]		SANTA CRUZ DE LA SIERRA-BOLMA			
		APROV.: WALKIRIA DATA: JAN/04		ESCALA: 1:10		TÍTULO: QUADRO DE COMANDO AUTOMÁTICO VISTAS EXTERNA E INTERNA		Nº. FENÔMENO: E\00\MAINTEN	
REV.	DATA								

LISTA DE MATERIAL DA PORTA		
SIMBOLOGIA	DESCRIÇÃO	FABRICANTE
NEG 5110	MODULO DE CONTROLE DO GMG	DEEP SEA
B1	BOTÃO LIGA A CARGA AO GMG	COMANDER
B2	BOTÃO DESLIGA CARGA	COMANDER
B3	BOTÃO LIGA CARGA REDE	COMANDER
AL	ALARME SONORO	SONALARME
EMG	BOTÃO DE EMERGENCIA	COMANDER


LISTA DE MATERIAL DA BANDEJA		
SIMBOLOGIA	DESCRIÇÃO	FABRICANTE
STR	SUPERVISOR DE TENSÃO DE REDE	DIAMOND
STG	SUPERVISOR DE TENSÃO DO GERADOR	DIAMOND
CFB	CARREGADOR DE BATERIA 220Vca/24Vcc	DIAMOND
DJ1 a DJ7	DISJUNTOR UNIPOLAR 10A Icc=5kA	ABB
DJ8	DISJUNTOR UNIPOLAR 15A Icc=5kA	LG
CAT/ACR/ACG	CONTATOR AUXILIAR 24Vcc	TELEMECANIQUE
RT	RELE TERMICO DE SOBRECARGA	WEG
CR/CG	CONTATOR DE FORÇA 220Vca, TIPO LC1 F185	TELEMECANIQUE
TC1 a TC3	TRANSFORMADOR DE CORRENTE 300/5A	SIEMENS
F1 a F3	FUSIVEL NH 300A	ELETROMECC
BP	BORNE DE INTERLIGACAO A PORTA	ENTRELEC
BS	BORNE DE INTERLIGACAO AO GMG	ENTRELEC
RTE	REGULADOR ELETRÔNICO DE TENSÃO	BASLER
e1/e2	CONECTOR-FUSIVEL	CONEXEL

REV.	DATA	POTÊNCIA: 160KVA	NOME	DATA	VISTO	CLIENTE: MAINTER S.R.L. SANTA CRUZ DE LA SIERRA-BOLÍVIA	OP.:
		TENSÃO: 380/220V/50Hz	PROJ. CLEDSON	JAN/04	<i>[Signature]</i>		4E0394
		RESPONSÁVEL TÉCNICO:	DES. CLEDSON	JAN/04	<i>[Signature]</i>		
		ALCIDES CARLOS R. DA SILVA	APROV. WALKIRIA	JAN/04	<i>[Signature]</i>		
		REG. CREA Nº 0346/83	HEIMER		ESCALA:	TÍTULO:	Nr. HEIMER:
			GRUPOS GERADORES		1:10	LISTA DE MATERIAL	Arq. HEIMER:
					2 / 7		E:\GC\MAINTER





CARGA

REDE

GEN




POTENCIA: 160KVA TENSÃO: 380/220V/50Hz		NOME: CLEDSON DATA: JAN/04		VISTO: [assinatura] DATA: JAN/04		CLIENTE: MAINTEN S.R.L. SANTA CRUZ DE LA SIERRA-BOLMA		OP.: 4E0394	
RESPONSÁVEL TÉCNICO: ALDORES CARLOS R. DA SILVA REG. CREA Nº 0348/83		APROV.: WALKIRIA DATA: JAN/04		ESCALA: 1:10		TÍTULO: DIAGRAMA DE FORÇA E COMANDO		Nº-HEMER: E/C/M/MAINTEN	
REV.	DATA	HEIMER GRUPOS GERADORES		3 / 7					



BAT	BATERIA 24Vcc	PK	PICK-UP MAGNÉTICO (DEEP SEA 5110)	T1	TERMOSTATO DE PRÉ-AQUECIMENTO	DESCRIBÇÃO	
MP	MOTOR DE PARTIDA	STA	SENSOR DE TEMPERATURA DA ÁGUA	R1	RESISTÊNCIA DE PRÉ-AQUECIMENTO	CLIENTE:	
ALT	ALTERNADOR DO MOTOR	SPO	SENSOR DE PRESSÃO DO ÓLEO	SP	SOLENOIDE DE PARADA	SANTA CRUZ DE LA SIERRA-BOLÍVIA	
RL1	RELÉ DE PARTIDA	RL2	RELÉ DE PARADA	---		TÍTULO:	
SIMB.	DESCRIBÇÃO	SIMB.	DESCRIBÇÃO	---		DIAGRAMA ELÉTRICO DO MOTOR	
POTÊNCIA: 160KVA		NOME		VISTO		OP.: 4E0394	
TENSÃO: 380/220V/50Hz		PROD.	CLEDSON	DATA	JAN/04	MAINTEN S.R.L.	
RESPONSÁVEL TÉCNICO:		DES.	CLEDSON	DATA	JAN/04	SANTA CRUZ DE LA SIERRA-BOLÍVIA	
ALCIDES CARLOS R. DA SILVA		APROV.	WALKIRIA	DATA	JAN/04	Nº-HEMER: ---	
RED. CREA Nº 0346/03		HEMER		ESCALA:	1:10	Arq-HEMER: ---	
REV.	DATA	GRUPOS GERADORES		4 / 7		ELOC-MAINTEN	







REGUA DE BORNES DO QTI - BS



REGUA DE BORNES DO MOTOR/GERADOR - BS



OBS.: CABOS DE BITOLA 1,5mm2 ONDE NÃO ESPECIFICADO

		POTÊNCIA: 160kVA TENSÃO: 380/220V/50Hz	NOME	DATA	VISTO	CLIENTE: MAINTER S.R.L. SANTA CRUZ DE LA SIERRA-BOLÍVIA	OP.:	
			PRD.	CLEDSON	JAN/04		<i>[Signature]</i>	4E0394
			DES.	CLEDSON	JAN/04		<i>[Signature]</i>	
			APROV.	WALKIRIA	JAN/04		<i>[Signature]</i>	
		RESPONSÁVEL TÉCNICO:	ESCALA: 1:10 5 / 7			TÍTULO:		
		ALCIDES CARLOS R. DA SILVA				DIAGRAMA DE INTERLIGAÇÃO	Nr. HEIMER:	
REV.	DATA	REQ. CREA Nº 0348/83					Arq. HEIMER: E\QC\MAINTER	



MATERIAL: ACRÍLICO TRANSPARENTE
 COR: LETRAS BRANCAS ; FUNDO PRETO

REV.	DATA	POTÊNCIA: 160KVA	NOME		DATA	VISTO	CLIENTE: MAINTEN S.R.L. SANTA CRUZ DE LA SIERRA-BOLIVIA	OP.: 4E0394
		TENSÃO: 380/220V/50Hz	PROJ.	CLEDSON	JAN/04	<i>CLEDSON</i>		
			DES.	CLEDSON	JAN/04	<i>CLEDSON</i>		
			APROV.	WALKIRIA	JAN/04	<i>WALKIRIA</i>		
		RESPONSÁVEL TÉCNICO: ALCIDES CARLOS R. DA SILVA REG. CREA Nº 0346/83	HEIMER GRUPOS GERADORES		ESCALA: 1:10	TÍTULO: PLACAS ACRÍLICAS	Nr. HEIMER:	
					6 / 7		Arq. HEIMER: E:\OC\MAINTEN	



MATERIAL: ALUMINIO COM ESPESSURA DE 1,0mm
 COR: LEGENDA PRETA ; FUNDO NATURAL
 COTAS EM MILÍMETROS

		POTÊNCIA: 160KVA	NOME		DATA	VISTO	CLIENTE: MAINTEN S.R.L. SANTA CRUZ DE LA SIERRA-BOLÍVIA	OP.: 4E0394
		TENSÃO: 380/220V/50Hz	PROJ.	CLEDSON	JAN/04			
			DES.	CLEDSON	JAN/04			
			APROV.	WALKIRIA	JAN/04			
		RESPONSÁVEL TÉCNICO: ALCIDES CARLOS R. DA SILVA REG. CREA Nº 0348/83	HEIMER GRUPOS GERADORES		ESCALA: 1:10	TÍTULO: PLACAS DE IDENTIFICAÇÃO DOS COMPONENTES	Nº. HEIMER:	
REV.	DATA				7 / 7		Arq. HEIMER: ELOC/MAINTEN	

**MANUAL TÉCNICO
(PADRÃO MANUAL – LH)**

INDICE

1. ACIONAMENTO DO GRUPO GERADOR
2. PARADA DO GRUPO GERADOR
3. INFORMAÇÕES COMPLEMENTARES
4. RELAÇÃO DOS DESENHOS

2 - PARADA DO GRUPO

- a) Desligar o disjuntor ou equipamento) localizada
- b) Desligar o interruptor (dependendo do modelo comando).
- c) Deixar o motor funcionar diminuir a temperatura
- d) Acionar a parada localizada no painel do modelo do equipamento horário (sentido de motor pare totalmente itens anteriores o (chicote) ao qual est

3 - INFORMAÇÕES

- a) Para manutenção de seguem com o equipamento
- b) Para uma vida mais semana, verificar o nível água destilada) e a funcionamento do procedimento de para ambos já descritos
- c) A fim de obter opcional um carregador

1 - ACIONAMENTO DO GRUPO

- a) Verificar o nível do óleo lubrificante no cárter do motor. Caso o nível esteja baixo, abastecer manual do motor.
- b) Verificar o nível da água localizada na parte superior do raio o mesmo.
- c) Verificar a quantidade de óleo Caso necessário completar.
- d) Girar a chave de ignição localizada posição 1. Acenderá uma lâmpada botoeira verde e o motor irá partir depende do modelo do equipamento a posição 1. e o motor começará a
- e) Ligar o interruptor da EXCITATE Dependendo do tipo de equipamento comando.
- f) Verificar a tensão no voltímetro comando, caso necessário ajuste
- g) Caso a tensão esteja dentro da faixa ou a chave seccionadora (dependendo localizado no quadro de comando





DIAGRAMA FUNCIONAL



QUADRO DE COMANDO

CONVENÇÃO	DESCRIÇÃO	TIPO	FABRICANTE
A	AMPÉRMETRO (88 x 96 mm)	FERRO MÓVEL	
CSA	CHAVE SELETORA DE AMPÉRMETRO	AUS1/10E	SEMTRANS
CSV	CHAVE SELETORA DE VOLTÍMETRO	V3/10E	SEMTRANS
DJ	DISJUNTOR TRIPOLAR 100A		
e1 e e3	FUSÍVEL 10-2A	VDR0	KOT0
h	SINALIZADOR DE GRUPO OPERANDO	XB2-EV164	TELEMECANIQUE
Hz	FREQÜENCIÓMETRO (90x90mm)		
TC1 e TC3	TRANSFORMADOR DE CORRENTE		
V	VOLTÍMETRO (88x100mm)	FERRO MÓVEL	
(1)	DE COBRE ELETROLÍTICO		


NOTA:

Qcm1.dwg

POTÊNCIA:	
TENSÃO:	
RESPONSÁVEL TÉCNICO:	Eng ALCIDES CARLOS ROBERTO DA SILVA CREA-0348/83
REV.	DATA

PROJ.	ALCIDES	DATA	VISTO	CLIENTE	OP.1
DES.	KARLLA	ABR/00			DESENHO Nº:
APROV.		ABR/00			SUBSTITUI Nº:
HEIMER GRUPOS GERADORES				ESCALA: TÍTULO: QUADRO DE COMANDO MANUAL DIMENSIONAL E DIAGRAMA FUNCIONAL	SUBSTITUIDO Nº: Nº PROJ.
		PL. 1			


	Page
1. Contents	
2. Assembly putting into operation / connection	2
3. Control elements	4
4. Display	4
5. Factory setting	5
6. Charging settings	6
6.1. One day of the week	6
6.2. Calendar mode / daily	7
6.2.1. AD = Automatic chargeover	7
6.2.2. d1A = Week-related time change	8-9
6.2.3. no = no chargeover	9
7. Standard settings / summary	11
8. Weekly time calculation	12-13
9. Fuel - charge - chem - time	14-15
10. Load switch	16
11. Technical data	17



2.1 Assembly

Fit the time switch

- on a DIN rail
 - optional wall surface mounting
- Surface mounting set for 2 and 3 module switch legs
Article No. 03.53.0060.2




2.2 Putting into operation

To make the device set to factory default, switch it to programming mode. Only in case of failure.

3.07 Factory key

- the time switch is restored
- It displays the time (day of the week)



2.3 Connection

See information on the unit

3.08 Press any key to activate the time switch

- the time and date is displayed

Note:


if no key is pressed the time switch is automatically activated after approx. 1-5 minutes




Safety instruction:

- When operating the clock safety low voltage, only safety low voltage may be connected.
- When operating the clock with higher low voltage, mains voltage (230 V) or line for low voltage may be connected. The connection of safety low voltage is not admissible in this case.

3 Control elements



4 Display



to winter time or to summer time. The time switch of a 3.2. Operating mode. The date and time and also the Operating mode. Also, also.

Operating modes:

- **AU** Automatic summer time controller switchover see 6.2.1

The switchover occurs on the dates defined by the following:

- **CHA** Weekday-related summer time controller switchover, see 6.2.2

You enter the start and end dates of summer time which applies to your location/season:

- 6.1 The first Sunday in April of the current year (start of summer time)
- the last Sunday in October of the year (end of summer time)

In the following years, changeover always occurs on the first day of the week in the current calendar week.

- **no** No changeover, see 6.2.3

AM/PM switch-over

Switch clock is in current operating mode

1. Press **n** and keep pressed
2. - Press **Res on**
 - all segments are displayed
 - after approx. 1 second the following appears: AM, 12:00 and 3 (Wednesday)
 - Operating mode AU is active = works sailing
3. Release **n**
4. Select operating mode as required, see 6.2.1 or 6.2.2 or 6.2.3
5. Set the current time over day and weekday, see 6.1

6. Changing settings

6

Note:

You can exit/undo any adjustments/changes you make if any time with the key **0**.

6.1 Time and day of the week



Press the **0** key once.

Set the time:

With the **h** key - hours
With the **m** key - minutes

Note for weekly time switch: if the Operating mode

no - no changeover
see 6.2.3


was selected, the day of the week must now be set.

- With the Day key select:
- 0 - Tuesday
 - 1 - Wednesday
 - 2 - Sunday




Press the **0** key once the input is entered.

6.2.1 AU :: 6.2.2 cHA :: 6.2.3 no




6.2.1 AU = Automatic changover

6.2.1 Press the key **AU** once




6.2.2 Press the + / - key once. AU appears



6.2.3 Press the Prog key once

Set the current year:
With the m key or the h key



6.2.4 Confirm with the Prog key

6.2.5 Set the current month and day:


With the m key - calendar month
With the h key - calendar day

Note:

With the Prog key press once or
twice (once for m or h) to skip
e.g. 20.03 and enter e.g. 20.10
of same line.



6.2.6 Press the **OK** key once.
The input is stored




6.2.2 cHA = Week day + calendar change





6.2.2 Press the **cHA** key once



6.2.3 Press the + / - key as often as
necessary until cHA appears




6.2.4 Press the Prog key once




6.2.5 Set the current year:
With the m key or the h key



6.2.6 Confirm with the Prog key




6.2.7 Set the current month
and day:
With the m key - calendar month
With the h key - calendar day



3.17 Continue with the Prog key. The start of summer time is displayed.




3.18 Set the individual summer time start: With the m key – month. With the n key – day.



3.19 Continue with the Prog key.



3.20 Set individual summer time end: With the m key – month. With the l key – day.



3.21 Press the ⌚ key once. The input is correct.

3.2 3 no = no change over only weekly time switch 10



3.22 Press the ⌚ key once.



3.23 Press the + key as often as necessary until no appears. The time switch operates without a delay.



3.24 Press the ⌚ key once. The input is correct.

Note:

See the day of the week on 3.1.


You determine the switching times and the switching state for the selected switching output channel. Signal: ON OFF = Channel 1
 ON OFF = Channel 2

These assignments are possible:

- Switching commands only for channel 1
- Switching commands only for channel 2
- The same switching commands for channel 1 and channel 2 (the switching time and switching state are identical)
- The same switching time for channel 1 and channel 2 but with a different switching state



302 Select free memory location:
 Press the Day key as often as necessary until --- appears





303 Set the switching times:
 With the min key - minutes
 With the hr key - hours
 For weekday adjustment, see Block formation of weekdays, page 9




304 Set the switching state:
 With the key
 ON or OFF

Note:
 The switching state for ON or OFF can be transferred. No signal - no switching.



305 Press the key to set the selected time range to either signal - to be switching or



306 Press the key. The next block


Block formation of weekdays: only weekdays are shown

Block formation of weekdays or individual days


You determine the weekdays for your switching program

Monday: 1 - Tuesday: 2 - Wednesday: 3 - Sunday: 7

Example: Monday: 1 - Friday: 18:00 ON; 22:00 OFF



307 Select free memory location:
 Press Day key as often as necessary until --- appears



308 Press the Day key
 At 7:00: 2 - the weekdays are set




309 Activating/deactivating days of the week:
 Joy the Day key stepwise




Note:

- Use the switching time and the switching state: ON = ON; OFF = OFF for the selected switching state (channel). For weekend switching commands, see 7





8.27 Press the Prog key once.
The input is erased.
A blank memory location is
displayed - for further settings



9.05 Press the \odot key once.
The input is stored.
The display shows the
current time.

9.27 Note:

After Prog procedure:

- read, modify or delete the time, date, switching program
- DCF synchronisation
- restoration of mains power the switching state of the time switch is updated automatically

14 Read - Change - Delete - Read

- You can read the program contents stepwise
- You can enter go or overwrite the program contents
- You can delete the program contents
- You can delete the date and time



Read


9.05 Press the Prog key step by step.
Each individual code is dis-
played until the end of the program
file:

- One time memory location
- One digit time memory location
for P1-31



Change

9.27 Press the Prog key step by step
as far as the switching
code/number/content which you
want to change/overwrite.
Change the switching command/
unit.
As described in
8. - With key block function




Delete - Individual switching commands

9.05 Press the Prog key step by
step as far as the switching
code/number/content which you
want to delete.


9.27 Press the \odot key once.
The switching command
is deleted.



Delete - All switching commands
 Press the Prog key once or as necessary until **Fr 28** appears.



Press the Clear key once. **CL** is in the display.



Press the Del key once or more. **All memory locations are deleted**.

The display shows the number of memory locations.



Reset

Press the Reset key once.

The set date and time are reset.

The factory setting:
 AU = automatic s/w
 time change with a minute
 (0 = 12 / 997, 00:00)

All segments are visible for approx. 2 seconds, then 00:00 appears.

AU = automatic s/w time change.

See point 5 and 6 for setting the current date.

Manual mode

You change manually = to current switching state.

However, this is only done by deactivating program fix parameters.

- 1 = channel 1
- 2 = channel 2

- automatic

= Manual mode

FX - continuous operation

= OFF

= ON

FX = Continuous ON

= ON

= OFF

FX = Continuous OFF

The switching state corresponds to the entered program.

You change manually = to the current switching state.
 The next switching command in the program is executed automatically again.

You change manually = to the current switching state.
 Only with the key can you switch from continuous operation back to Automatic mode.

1 channel daily program 1 channel weekly program
2 channel weekly program

Dimensions (H x W x D)	45 x 30 x 60	40 x 45 x 60
Distribution cabinet	40 x 30	40 x 30
Weight (g) (approx.)	170	170
Construction	via rail - printed	via rail - printed
Power consumption	see rail - printed	see rail - printed
Switch capacity (AC/DC)	16 A/250 V AC	16 A/250 V AC
— inductive load cos φ = 0.8	2.5 A/250 V AC	2.5 A/250 V AC
— glow lamp load	1000 W	1000 W
Switching speed	indefinite time	indefinite time
Switching contacts	1 or 2 changeover contact	1 or 2 changeover contact
— travel, contact class	II	II
Protection type	IP 20	IP 20
Operating accuracy	— ± 0.5% / any of +20°C	— ± 0.5% / any of +20°C
DCI 27 radio channel no.	—	—
Operating reserve type	lithium	lithium
Operating reserve	3 years from factory	3 years from factory
Switching switching time	3 minutes	3 minutes
Programmable	every minute	every minute
Memory bank type	12	20/30
Switching (manual) set	yes	yes
— lock switch	Automatic / presel. lock	Automatic / presel. lock
	× ON	× ON
	Fix OFF	Fix OFF
Switching state display	yes	yes
lock (manual) weekly	—	lock gas green
Setting/working window	in time / any selection	in time / any selection
Connectivity type	capillary - screw terminal	capillary - screw terminal
Ambient temperature	0°C ... +50°C	0°C ... +50°C
Lead wire cable	yes	yes